


# **ELECTRONIC SIREN**

## **AS-422/6S N** **(NORWAY. POLICE)**

# AS-422/6S N (Ref:2020141N)

## GB OPERATING INSTRUCTIONS

(\*SEE THE WIRING DIAGRAM IN THE STANDARD INSTRUCTIONS FOR USE MANUAL )



ON

OFF

DEACTIVATES ALL FUNCTIONS

KEEP BUTTON PRESSED

(ON-OFF)

OFF

bla bla bla

VOL

bla bla bla

bla bla bla

YELP (ON)

2B ON 1B ON

10s

YELP

(f=600-1350Hz 160c/min.)

4A ON	5A OFF
4A OFF	5A ON

WAIL (ON-OFF)

2B ON 1B ON

WAIL






(f=600-1350Hz 12c/min.)

4A ON	5A OFF
4A OFF	5A ON





THIS FUNCTION CONTROLS HIGH / LOW INTENSITY OF AN EXTERNAL POWER SUPPLY.

NATT (ON-OFF)

3B ON-OFF



**GB SIREN CONTROL BY HORN (AUTOMOBILE) / BUTTON (MOTORBIKES)**



THE SIREN WILL NOT BE DEACTIVATED IN THE EVENT THAT A LAMP FAILURE IS DETECTED (BY AN OPTIONAL EXTERNAL DISPOSITIVE)